



## **Eurofone C33-B & C33-W**

### **User manual**



## **Contents of the package**

### **C33**

- ✿ 1 base station
- ✿ 1 connector cable
- ✿ 1 mains adapter 6 VDC / 300mA
- ✿ 1 handset
- ✿ 2 rechargeable batteries NiMH AAA 500 mAh
- ✿ 1 user manual

### **Location**

To obtain the best possible range, we recommend positioning the telephone in a location central to your sphere of activity. Avoid positioning the telephone in niches, recesses and behind steel doors.

The maximum range between the base station and handset is approximately 50 meters indoors and 300 meters outdoors. Depending on the surrounding conditions as well as spatial and structural factors, the range may be smaller. Silent zones can occur due to the digital transmission in the frequency range used – even within the range, depending on the structural environment. In this case the transmission quality may be reduced through the incidence of short breaks in transmission. Normal call quality can be restored if you move slightly out of the silent zone. If the range is exceeded, the call will be disconnected unless you move back into range within five seconds.

To avoid radio signal interference from other electronic equipment, we recommend that the base station and handset are situated at the greatest possible distance (min. 1 meter) from other equipment.

## **Setting up the telephone**

### **Setting up the base station**

- ✿ *Do not expose the base station to direct sunlight.*
- ✿ *Protect the base station against moisture. Do not position the base station in rooms exposed to condensation, corrosive steam or excessive dust. Condensation can be present in basements, garages, conservatories or sheds.*
- ✿ *The ambient temperature must be between 5 °C and 40 °C.*
- ✿ *Avoid positioning the telephone near heat sources such as heating elements or near obstacles such as metal doors, thick walls, niches and cupboards.*

There is no mains switch on the base station. For this reason the socket to which it is connected must be easy to access.


### **Listening protection**

When you are on the telephone, the base station and handset are connected to each other over a radio link. The base station handles switching between the telephone network and the handset. To ensure that no-one can eavesdrop or telephone at your cost, the base station and handset exchange codes. If the codes do not match, the connection with third-party handsets cannot be set up.

## Setting up the telephone

### Connecting the phone

Before you can start using your telephone you must plug in the telephone connector cable and the mains cable.



### Safety note

Use only the supplied mains adapter 6 vdc / 300 mA for the base station.

#### ① Mains cable

First, insert the mains cable in the socket marked with the mains connector symbol on the base of the base station. Then insert the mains plug in the 230 V socket.

---

**Note** Your telephone will not function if the mains connector is not plugged in or during a power failure.

---

#### ② Telephone connector cable

Insert the one end of the telephone line cord into the wall jack and the other end into the connector marked with the telephone symbol on the base station.


### Setting up the handsets

Your handsets will be ready for operation (for making or accepting calls) only once the batteries have been fully charged for the first time.

### Inserting the rechargeable batteries

The bottom part of the handset contains a battery compartment for housing two type AAA batteries (microcells).

## Setting up the telephone



### **Removing the battery compartment cover:**

Slide the battery compartment cover downwards (approx. 3 mm) and lift it up.



### **Safety note**

Use only approved rechargeable batteries type NiMH AAA 500 mAh.

### **Inserting the two rechargeable batteries (note the polarity!):**

Insert the batteries in the battery compartment. Make sure the polarity is correct. Insert the batteries so that the flat end (negative polarity) of the battery is pressing against the spring. The handset will not function if the batteries are incorrectly inserted. This may result in damage. Replace the compartment cover by placing it approximately 3 mm offset and slide it upwards until it clicks into place.

### **Charging the batteries**

The batteries are not yet charged when you first unpack the telephone. Insert the handset in the base station for charging. The flashing battery symbol on the handset shows the charging status. The batteries will take around 14 hours to fully charge (initial charge).

Do not insert the handset in the base station without batteries.

## Setting up the telephone

Once the new batteries have been inserted, the display on the handset indicates the actual charging status only after a complete charging cycle.

---


**Note** You can replace the handset in the base station after every call. Charging is electronically controlled to ensure optimal charging of batteries in different charge states. Avoid removing the batteries from the handset for no good reason, since this affects the optimum charging cycle.

You can telephone for up to 10 hours with fully charged batteries. The handset has a standby time of up to 100 hours. When Full-Eco is switched on and up to 200 hours if the function is switched off.

If the battery charge status has reached its lower limit, the battery symbol flashes in the display and a warning signal is heard. You have 10 minutes of talk time left.


---

### C33




## Get to know your telephone

### Handset keys



## Getting to know your telephone



**Softkeys (multifunctional keys)** The functions of the softkey vary depending on the current operating mode and are shown in the display.



**Navigation key** For scrolling up/down or right/left.


- ▲ Open call list
- ▼ Open redial list



**Call key**



**“End call” key** During conversation: end call  
Long press in standby: switch the handset off  
In a menu: exit the menu



**Alphanumeric keypad** For entering telephone numbers and text. Press and hold down “0” when entering a telephone number to insert a dialling pause between two digits.



**Voicebox (network answering machine)** Press and hold down for direct access to network answer machine.



**Asterisk key** For entering asterisks. Press and hold down to switch handset ringer on/off.



**Hash key** For entering the hash symbol. Press and hold down to switch keylock on.



**Enquiry key** Press key R to activate some network functions.



**Phonebook** Open the phonebook.














**Loudspeaker key/Handsfree** Activate/deactivate the loudspeaker



## Getting to know your telephone

### Handset display symbols

-  **Coverage symbol**  
Displayed when the handset is within range of the base station. Flashes when out of range of the base station.
-  **Open menu or menu option list**
-  **Internal call**
-  **Active call**
-  **Handsfree is activated**
-  **You have messages on your voicebox\***
-  **Keypad is locked**
-  **Ringer is switched off**
-  **"Mute" is activated, the microphone is switched off**
-  **Alarm is activated**
-  **Battery charge status**

\* Function dependent on network operator.

Contact your network operator to find out whether this service is supported

## Getting to know your telephone


### Switch handset on/off


- Press and hold the **End call key** (approx. 5 sec).
- Press and hold the **End call key** to reactivate the handset.

### About the menus


#### Menu navigation

In standby when pressing the soft key under .

Select the menus with the navigation key .





Press **OK** to confirm. To open the options list, use the navigation key  to scroll down the list to the preferred option, and confirm the option by pressing **OK**.

#### End menu

To exit a menu, press the **End call key** .


#### Set language

- Language default setting on delivery is English.
- To change the language:


1. Press the soft key under .
2. Press  to scroll through the list, select *HS SETTINGS* and press **OK** to confirm.
3. Press  to scroll through the list, select *LANGUAGE* and press **OK** to confirm.
4. Press  to scroll through the list, select the desired language and press **OK** to confirm.

## Telephoning


### Making an external call

Press , wait for the dialling tone and dial the number.

### Call preparation


1. Enter the number. If you enter an incorrect number, you can:
  - delete it by pressing repeatedly the right softkey.
  - move the cursor to the desired character by pressing the navigation key (left/right).
2. Press  to dial the number.

### Ending a call

Press  or replace the handset in the base station.




### Accepting a call

The caller's number or name (if already saved in the phonebook) is displayed only if your network operator supports the Caller Identification Presentation (CLIP) function and you have subscribed to this service.


Press  to accept the call.

### Handsfree operation

Activating handsfree before a call:

1. Press  until you can hear the ringing signal and  appears.
2. Enter the desired number, the number is dialed.
3. Short press  deactivates handsfree speaking.


Switching to handsfree speaking during a call:

Press  during a call to switch to handsfree operation.



To deactivate handsfree speaking, press again .

## Telephoning

### Handset/handsfree volume

You can adjust the handset and handsfree loudspeaker volume independently in 5 steps. Press  during a call to adjust the volume. The selected setting is saved after the end of the call.

### Handset secrecy




1. Press  during a call. This switches the microphone off and your caller cannot hear you.
2. Press  to switch the microphone on.

### Redial

The 10 last-dialled numbers are saved in a redial list. If a name and number are already stored in the phonebook, the name is shown instead of the number.

### Redialing a number from the list

If the telephone is in idle mode:

Press  to open the redial list and press  to scroll through the list. Press  as soon as you have reached the number you are seeking.

---

**Note** • To open the redial list the telephone **must be** in idle mode.

---

## Telephoning

### Deleting individual entries/entire redial list

Press ▼ to open the redial list. Use ⏮ to scroll through the list until you reach the entry you are seeking. Press the soft key under ⏮ and delete the entry or the entire list.



### Copying numbers from the redial list to the phonebook

Press ▼ to open the redial list. Use ⏮ to scroll through the list to find the entry you are seeking. Press the soft key under ⏮, select *ADD*. Enter the name, confirm the number, select the desired ringer melody and save the entry.

## Telephoning




### Group call (paging)

You can activate a group call to locate a mislaid handset.

1. Press the **paging key**  on the base station. You will hear an acoustic signal on the handset(s) registered with the base station.
2. Press the **paging key**  again to end the ringing signal or press key on the handset.

### Keypad lock

If you want to carry the handset around, you can activate the key lock. This prevents you inadvertently dialing a number.

1. Press and hold down . The keypad is locked and the display shows .
2. To unlock the keypad, press and hold  again.

---

#### Note


If the keypad is locked,


- Incoming calls can still be accepted.
  - You cannot dial a number or access menus.
-

## Telephoning

### Internal calls

You can call other handsets which are registered with your base station. This allows you to make internal calls free of charge.

1. Press the soft key under , select the relevant handset number and press **OK** to confirm.

Pressing  automatically dials the second handset if only two handsets are registered with the base station.

2. Press  to end the call.

### Internal enquiry call

You are conducting an external call and want to call an internal party without ending the external call. If the second handset answers, you can talk to the internal call partner without the external caller hearing you.

1. Press the soft key under .

2. Select *INTERCOM*, press **OK** to confirm. The external call is put on hold.



If only two handsets are registered with the base station, the second handset is automatically dialed. If you have more than 2 handsets registered, select the desired handset number and press **OK** to confirm.

3. To return to the external call, press key .

## Telephoning


### Conference

You have two active calls (1 internal and 1 external), one of which is on hold.

1. To connect all three call partners with each other, press and hold  until *CONFERENCE* appears.
2. Press  to end one of the calls. The remaining call partners are automatically connected with each other.

### Call transfer to another handset


You can transfer the call you are conducting to another handset.

1. Press the soft key under  .
2. Select *INTERCOM*, press **OK** to confirm.

If only two handsets are registered with the base station, the second handset is automatically dialed. If you have more than 2 handsets registered, select the handset to which you wish to transfer the call and press **OK** to confirm. The external caller is put on hold.

3. If the second handset answers, you can talk to the internal call partner without the external caller hearing you. Press  to transfer the call.

---

**Note** If the second handset does not answer, you can end the ringing signal and return to the original call by pressing key .

---





## Phonebook

You can store up to 50 names and numbers in the phonebook on each handset. Every entry contains a name and telephone number. Names can be up to 12 letters long and numbers up to 20 digits long.





### Phonebook entries

#### Adding a new entry

If the telephone is in idle mode:




1. Press  to open the phonebook.
2. Press the soft key under .
3. Select *ADD* and enter the name, the number, select the desired ringer melody and save the entry.


#### Tips for entering names/numbers

- Press  to insert a space, or press and hold  to insert a dial pause.
- Press the soft key under  repeatedly to delete digits or press and hold  to delete the entire entry.




## Phonebook

### Dialling numbers from the phonebook

1. Press  to open the phonebook.
2. Use  to scroll through the phonebook, select the entry you are seeking and press . The number is displayed and dialed.

You can also search by name: press the first letters of the name and press .

### Editing entries

1. Press  to open the phonebook. Use  to scroll through the list to find the entry you are seeking, and press the soft key under .
2. You have then the following options:
  - **ADD** Add a new entry.
  - **VIEW** Show the details of a number.
  - **EDIT** Modify a name or number.
  - **DELETE** Delete the entry.
  - **DELETE ALL** Delete the entire phonebook.
  - **PB STATUS** Check how much space is left for storing entries.

## Call list\*


If your network operator supports caller ID presentation\* (CLIP), the caller's number (if he did not not withheld his own number) is displayed before you accept the call. The call list can hold up to 20 entries. If the list is full, the oldest entry is overwritten by the most recent entry.

### Dialling a number from the call list

1. Press ▲ to open the call list.


Or

Press the soft key under , select *CALL LIST* and press **OK** to confirm.

2. Select the desired entry and press  to dial the number.

### Editing entries in the call list

1. Press ▲ to open the call list.

2. Press the soft key under . You have then the following options:

- *ADD* Save numbers from the call list to the phonebook.
- *DELETE* Delete a call list entry.
- *DELETE ALL* Delete the entire call list.
- *DETAILS* View the details of a call list entry.
- *CATEGORY* Save all incoming calls in the call list or only the missed ones.


\* Function dependent on network operator.

Contact your network operator to find out whether this service is supported

### **Voicebox (Network answer machine)**

Many network operators offer the option of setting up a network answer machine (voicebox).

To use the network answer machine, you need to send certain codes to the network. Ask your network operator for details.

To access new messages quickly and simply, press and hold down  for around 2 seconds to automatically dial the access number of your voicebox.


---

**Note** Please note that this service is a supplementary network service and thus subject to availability from your network operator.

Contact your network operator for details and the appropriate codes to activate this service.


---

## Handset settings

1. Press the soft key under . Select *HS SETTINGS* and press **OK** to confirm.
2. You have then the following options:
  - *ALARM*      Activate the alarm function, enter the desired alarm time and activate or deactivate the *SNOOZE* function.
  - *RING SETUP* You can program different ringer melodies for internal and external calls. Set the preferred ringer melody and the associated volume. Select volume *OFF*, to switch the handset ringer off.
  - *TONES*      Your telephone supports various tones which you can activate or deactivate:
  - *KEY TONE*    Every time a key is pressed, a brief beep is heard.
  - *BATTERY TONE* Sounds when the batteries are running low.
  - *OUT OF RANGE* A warning beep is sounded if you exceed the maximum range. Move closer to the base station.
  - *LANGUAGE*    Select the display text language.
  - *RENAME HS*    To better distinguish between handsets, you can give each handset a name.

- *HS DISPLAY* Select the handset display in idle mode (handset name or time).
- *AUTO ANSWER* An incoming call can be accepted by pressing the talk key. If you activate Auto Answer, you can accept a call simply by lifting the handset from the base station without pressing any key.
- *DATE & TIME* Select the desired time and date format and enter time and date.
- *SELECT BASE* See chapter “Additional handsets/base stations”.

## Base settings

1. Press the soft key under . Select *BS SETTINGS* and press **OK** to confirm.
2. You have then the following options:
  - *BS RINGER* You can program different ringer melodies for the base.
  - *RING VOLUME* Set the desired volume. Select *OFF*, to switch the base ringer off.
  - *DELETE HS* See chapter “Additional handsets/base stations”.
  - *DIAL MODE* Select tone or pulse dialing: *TONE* Normal dialing procedure on analog lines. *PULSE* May be required for connecting older telephone systems. Please refer to the relevant documentation.
  - *FLASH TIME* Select the flash time (when pressing key R) for the analogue network functionalities in your country:
    - SHORT* corresponds to 100 ms
    - MEDIUM* corresponds to 300 ms

*LONG* corresponds to 600 ms

Contact your network operator for details. On delivery, the flash time is set to the value for the country in which you have purchased the telephone

- *CHANGE PIN* You can change the system PIN (0000 by default).
- *ECO RANGE* See chapter "ECO Range / Fulleco".
- *FULLECO* See chapter "ECO Range / Fulleco".
- *HS PRIORITY* When you have several handsets registered to your base: You can set that all handsets will ring on incoming calls or that a selected handset will ring first.

## **Base settings**

### **ECO Range / Full eco**

#### **Full eco - Multi Handset Low Radiation Mode**

Electromagnetic radiation is shut down between the base station and all declared handsets.

Handsets and base station are waiting for a wake-up signal either in form of an incoming call, when activating a handset or when the system synchronises data.

#### **Radiation reduction in communication**

65% radiation reduction on the handset is achieved when it is near the base station. The handset's power transmission is regulated; the power transmitted from the handset is automatically reduced to the lower level, depending on the distance to the base station. This feature is activated when *FULLECO* is set to **ON**.

1. Press the soft key under . Select **BS SETTINGS** and press **OK** to confirm.

2. You have then the following options:

- **ECO RANGE** You can reduce the range of the base (**HALF RANGE**) or set **FULL RANGE**.
- **FULLECO** Activate or deactivate the function.

---

**Note**

- Default setting on delivery: Full eco mode is activated.
- Other cordless DECT products in range may interfere with the ECO Mode.

---

## **Additional handsets/base stations**

### **Registering additional handsets**


You can register up to 5 handsets with the base station. The base station must be within range.

---



**Note** If you purchase additional handsets for your base station,

- the batteries must first be fully charged!
- the handsets must be registered with the base station before use!

---

1. Press and hold down the **Paging key**  on the base station for around 10 seconds.



2. Release the **Paging key**  when you hear a beep on the base station.
3. On the handset, press the soft key under . Select *REGISTRATION* and press **OK** to confirm. Select the base station, enter the base station system PIN (default on delivery: 0000) and press **OK** to confirm. If the declaration is successful, the handset is automatically assigned the next available handset number.

### **Deregistering a handset**

You can deregister a handset from the base station. The base station must be within range.

Press the soft key under . Select *BS SETTINGS* and *DELETE HS*, press **OK** to confirm and deregister the desired handset from the base.

---

**Note** You can only deregister a different handset from the handset you are using for this operation.

---


### **Selecting the base station**

Press the soft key under . Select *BS SETTINGS* and *SELECT BASE*, press **OK** to confirm and select the desired base station.

## **Maintenance**

### **Reset**

You can reset the telephone to default status.

1. Press the soft key under . Select *DEFAULT* and press **OK** to confirm.
2. Enter the system PIN (0000 on delivery).
3. Press **OK** to confirm the reset.

## **General information**

### **Approval and conformity**

This analogue telephone DECT complies with the basic requirements contained in the R&TTE Directive 1999/5/EC on radio equipment and telecommunications terminal equipment and is suitable for connection and operation in the member state indicated on the base station and/or packaging.

The declaration of conformity may be viewed at: [www.qualitel.co.za](http://www.qualitel.co.za)



The CE symbol confirms the conformity of the telephone with the above directive.

## **Warranty conditions**

Your telephone is subject to a six month guarantee from the date of purchase.

As evidence of the date of purchase, please keep the sales receipt. All defects attributable to material and manufacturing faults will be corrected free of charge within the warranty period, either by repairing or replacing the defective equipment.

The warranty does not cover damage caused by misuse or negligence or by excessive voltage. For example, faults on the telephone or power line or damage caused by lightning.

The warranty does not cover expendable materials (battery cells), defects which affect the value or use of the equipment only insignificantly, and damage caused by incorrect use, ordinary wear and tear, or manipulation by third parties.

This warranty does not cover consequential damage caused by the use, failure or defectiveness of the product. In particular, no liability whatsoever is accepted for damage to property and pecuniary loss.

To claim under this warranty, please contact the retailer where you purchased your telephone.