


Trend

User Guide



Plug the telephone line cable into the socket as shown

1 Making and answering calls

To make a call

- 1 Lift the handset and wait for Dial tone
- 2 Dial the telephone number using the keypad

Last Number Redial

To make a repeat call to the last number you dialled (up to 32 digits):

- 1 Lift the handset and wait for Dial tone
- 2 Press LNR

Secrecy

While you are on a call, to mute the mouthpiece so that your voice cannot be heard

- 1 Press and hold SEC

Use on a PBX

If you are using your Trend on a PBX, and the PBX User Guide tells you to press RECALL, press the button on your Trend.

To make a call:

- 1 Key In the outside line access digit then press LNR
- 2 Dial the telephone number

Technical details

| | | |
|---------------------|---|---------|
| Temperature range | Operating 0°C to 40°C | |
| | Storage -20°C to 60°C | |
| Approvals standards | EN55022 | EN55024 |
| | EN60950 | |
| | iCTR37 | CTR38 |
| PBX compatibility | Pause length: 3 seconds. Signalling type: DTMF (dual tone multifrequency), also called tone dialling. | |

If you need help ...

The **Help Line** is available from 9.00 am to 5.00 pm, Monday to Friday, on **0845 345 9677** Calls are charged at Local Call rate.

2 Troubleshooting

! The Trend must be serviced by trained engineers. NEVER attempt any repairs or adjustments yourself - you could invalidate the Guarantee.

If the phone does not ring ...

Make sure your Trend is fully plugged into the telephone line socket.

Check that the total REN value of all equipment connected to your telephone line is no more than 4. Disconnect one or more telephones and see whether that helps.

If you cannot make Calls ...

Make sure your Trend is fully plugged into the telephone line socket.

Disconnect all other instruments connected to the same line as the Trend and see whether you can make a call.

Disconnect the Trend from the telephone line and plug a different phone into the socket. Try making a call. If this works, the line is OK.

If you are using a two-way socket adapter, remove it and plug a telephone directly into the socket. If the call now works, the adapter may be faulty.

If you think the fault may be on the exchange line, contact the service provider .

BINATONE TELECOM PLC
1 Apsley Way London NW2 7HF, United Kingdom.
Tel: +44(0) 20 8955 2700 Fax: +44(0) 20 8344 8877
e-mail: binatoneuk@binatone telecom.co.uk



EC Declaration of Conformity


We the manufacturer / Importer : Binatone Telecom Plc
1 Apsley Way London
NW2 7HF, United Kingdom.

Declare under our sole responsibility that the following product

| | |
|--------------------|--------------|
| Type of equipment: | Corded phone |
| Model Name: | Trend |
| Country of Origin: | China |
| Brand: | Binatone |

complies with the essential protection requirements of R&TTE Directive 1999/5/EC on the approximation of the laws of the Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to **electromagnetic compatibility (EMC)** and the European Community Directive 2006/95/EC relating to **Electrical Safety**. Assessment of compliance of the product with the requirements relating to the essential requirements according to Article 3 R&TTE was based on Annex III of the Directive 1999/5/EC and the following standard:

EMC: **EN 55022:2006**
EN 55024:1998+A1+A2



Electrical Safety: **EN 60950-1:2006**

The product is labelled with the European Approval Marking CE as show. Any Unauthorized modification of the product voids this Declaration.

Manufacturer / Importer
(signature of authorized person)

Signature: (K.H. Mueller, CT0)



London,
Place & Date: 8th Nov, 2009

3

Guarantee and service

The BinatoneTrend is guaranteed for 12 months from the date of purchase shown on your sales receipt. The Guarantee does not cover damage by misuse or negligence, or by excessive voltages - for example, faults on the telephone line, or lightning. This does not affect your statutory rights.

Please keep your sales (till) receipt - this is your guarantee. You should also keep the original packaging material.

In the unlikely event that you need to return your Trend to our Repair Centre while it is under guarantee, there will be a handling charge.

While the unit is under Guarantee

1. Disconnect the Base unit from the telephone line and the mains electricity supply.
2. Pack up all parts of your Trend, using the original packaging.
3. Return the unit to the shop where you bought it, making sure you take your sales receipt.

After the Guarantee has expired

If the unit is no longer under Guarantee, first follow steps 1 and 2 as for repair under Guarantee. Then ...

3. Call our Service Department on **0845 345 9677** and ask for a quotation of the repair charge and details of where to send your Trend for repair.
4. Make sure you include with your Trend:
 - your name and address.
 - a cheque or postal order for the value of the repair charge.
5. Return your Trend to the address given by the Service Department.

Connection and conditions for use

You can connect your Trend, to public networks in the UK; or to an approved PBX using DTMF signalling.

Each item of telephone equipment (phones, fax machines etc.) has a ringer equivalence numbers (REN). The RENs of all equipment connected to an exchange line must not add up to more than 4 otherwise, one or more phones may not ring and/or answer calls correctly.

Trend has a REN of 1, and most other telephones have a REN of 1 unless marked otherwise.

Care of your Trend

- Do not clean your Trend with solvent chemicals, abrasives or spray cleaners which might get inside the case and cause damage not covered by the Guarantee. When necessary, clean it with a damp cloth.
- Keep your Trend away from hot, humid conditions or strong sunlight.
- Every effort has been made to ensure high standards of reliability for your Trend. However, if something does go wrong, please do not try to repair it yourself - consult your supplier or the Binatone Help Line.

Electrical safety


- DO NOT install the Trend near a sink, bath or shower or anywhere it could get wet. Electrical equipment can cause serious injury used while you are wet or standing in water.
- If the unit ever falls into water, DO NOT retrieve it until you have unplugged the telephone line plug from the telephone socket; then pull it out by the unplugged cable.

Wallmounting instructions

Please read the instructions on this template carefully before you start to wall mount your telephone. If you prefer, you can stand your telephone on a level surface


BE CAREFUL - check that there are no electrical wires hidden in the wall.

- 1 Use this template for wallmounting, marking the wall at the fixing centres. The marks should be **83 mm** apart
- 2 Using screws (not supply with the unit) screw in at the two marked locations, leaving approx. 7mm (1/4") between the wall and underside of screw head.
- 3 Tuck the telephone line cord into the grooves on the cradle. Make sure that the parking hook lever is pushed to the top position.
- 4 Hang the cradle unit on the screws using the wallmounting slots on the underside of the unit. You may need to remove the telephone from the wall and tighten the screws so that the cradle is securely fixed and does not wobble.
- 5 Rest the handset on the cradle using the parking hook on the cradle and the parking recess under the earpiece on the handset



Reset the hook on the cradle.

This hook is designed to keep the handset in place when the telephone is vertical on the wall. The hook on the upper part of the cradle is there to support the handset if you need to leave the phone temporarily during a call.



Help Line: **0845 345 9677**

BTP Ver 1.0 Nov,09

Binatone

If you need help ...

The **Help Line** is available from 9.00 am to 5.00 pm, Monday to Friday, on **0845 345 9677**. Calls are charged at Local Call rate.