

User Manual

•Product: Smart Wi-Fi Switch Rated Voltage: AC 90-250VRated Current: 10A(Max) app from the APP Store or Google play •Enter the register/login interface, enter the •AC Frequency: 50-60HZ phone number to receive a verification Max Power: 2200W for 220\ code to register or through other methods at the bottom of page connecting to related authorization interface to log in. Installation Diagram •Note: Our APP only supports 2. 4GHz Wi-Fi

Specifications

before installing this product.

Live On/Off Button

Press and hold

Input Output for 5 seconds to restore factory settings

Note: To avoid electric shock disconnect the power

•Scan the QR code to download "Smart Life"

After installation of the smart switch ON/OFF button for 5 seconds, the

ON/OFF button for 5 seconds, the indicator light flashes rapidly. The smart switch (breaker) is now ready for pairing then tap the "Breaker (Wi-Fi & Bluetooth)" Connect your mobile phone or tablet to your Wi-Fi router which has internet

connectivity.

of the "HOME" screen on your mobile CONFIRM".

Part1: Download Registration Part 2: EASY MODE (Recom-

The application will automatically

recognize the Smart Switch (Breaker) and ask to pair the device. icon in the application.

•Ensure that the indicator light on the

switch is flashing rapidly.

phone or tablet.

•Select on your mobile phone / tablet " confirm indicator RAPIDLY BLINK". ·Select your local Wi-Fi and enter the •Tap "confirm indicator slowly blink" on •Tap the "+" icon at the top right corner correct password then tap "NEXT" / " your mobile phone / tablet.

 Connect your mobile phone / tablet to the devices hotspot, tap "GO TO CONNECT". *Choose Wi-Fi "SMART LIFE-XXXXX" then If easy mode pairing failed, try switch return to Smart Life App.

•Wait for successful configuration then

tap "DONE".

•The device starts pairing automatically. Wait for "DEVICE ADDED SUCCESSFULLY" displayed on your mobile phone or the switch for 5 seconds, the indicator light flashes slowly. •Then press "DONE"

•Select your local Wi-Fi and enter the

correct password then tap "confirm".

Part 4: PROFILE
On the home screen On the home screen

bottom right corner to update your

Message Center FAQ & Feedback Featured

HomelCit Information

Part 5: SMART SWITCH

Third-Party Voice Services Novo >

•If set to "ON", the Smart Switch

(Breaker) will remain off after a

same as prior to a power outage

power outage.

• On the Home Screen, tap on the

Personalize your Smart Switch/

•If set to "OFF", the Smart Switch

maximum output current. •If set to "memory", the Smart Switch (Breaker) will resume working the

·A qualified electrician should install this

·Stow the product out of reach of childre ·Do not overload this product, refer to the

 Do not disassemble this product, it may Do not push foreign objects of any kind

into this product through cabinet slots

as there may be a risk of electric shock.

Do not spill any liquids onto this product.

·Stow the product in a way that it cannot cause injury to persons.

caused by misuse or negligence

or by excessive voltage. For example,

faults on the power line or lightning.

This product is guaranteed for a period

se as shown on your sales receipt The guarantee does not cover damage

This smart device is compatible with

Amazon Alexa and Google Home

























